

## **Operating Instructions for: Medicine Bawl**

Medicine Bawl is a vintage styled wah with modern features. Includes user adjustment for sweep and gain. Frequency range from 300Hz - 3.0Khz

Input-Instrument in. Unplug when not in use to conserve battery life.

Note: Input is on the right side of wah, next to DC jack.

Out-Ouput to amplifier

-9VDC jack-for use with -(Negative) center, 9VDC, filtered, and regulated power supply.

On/Off-Turn the wah on/off rock pedal fully forward to activate switch.

Gain/Trim Pot-Located in the center of the circuit board. Adjust to change the input gain of the wah.

Sweep/Trim Pot-Located near the bottom of the circuit board just in front of the yellow or red inductor. Adjust to change the sweep curve of the wah.