

Operating Instructions for: Hematoma

Hematoma is a two channel bass pedal consisting of a 5db preamp and an overdrive. The preamp and overdrive can be used independently or can be combined.

Input-Instrument in. Unplug when not in use to conserve battery life.

Out-Out to amp

-9VDC jack-for use with -(Negative) center, 9VDC, filtered, and regulated power supply.

Pre-Gain control-Varies the level of the pre-amp up to 5db boost.

Gain control-Varies the amount of overdrive.

Level control-Varies the amount of output for the overdrive channel.

Tone control-Varies the amount of bass or treble for the overdrive channel.

EQ-Shift switch-Changes the sweep of the tone control and provides a warmer smoother tone when engaged. (Switched to the right)

BO-Switches on and off the overdrive effect.

BP-Switches on and off the bass pre-amp effect.